



Step1 using the plastic adaptors and short tube to locking crossbeam ;locked screwsA
 Step2 opening the tripod, and locking the screw B
 Step3 using short tube to connection between tube C & D, and locking the screw C
 Step4 insert tube C , and locking the screw.